

Automotive AC(Alternating Current)

- AC current is contained in the Inverter/Converter until power is requested by the driver.
- Current transfers to the Traction Motor driving the wheels.
- If AC circuit is damaged, AC current will not flow to terra firma ground or to the body of the vehicle.
- Due to the location of the AC circuit wiring,(mainly in the engine compartment) any involvement during an extrication is unlikely.