

Submersion Procedures



Handle vehicle that is submerged either partially or fully by disabling the HV battery pack, SRS airbags, and fuel pump after removal from water.

- Drain water from the vehicle if possible.
- Follow power down procedures
- When the high voltage battery is under water, it will fizzle and short internally. Hydrogen/oxygen gas may accumulate in sealed passenger compartment
- Vent appropriately.
- The high voltage battery will be discharged when the fizzing or bubbling has completely stopped.

