


# Component Locations: Truck

- High voltage
  - Service disconnect button
  - AC traction Motor
  - Generator – three phase AC
  - Lithium-ion battery pack mounted on frame
  - Orange wires



Apply air brakes  
Disconnect low voltage battery(s)