

Power Down Procedures/Warnings

- The 12 volt auxiliary battery supplies power to the SRS/Airbag control unit.
- The SRS/Airbag system is potentially hazardous to Firefighters and EMS personnel until the 12 volt auxiliary battery has been disconnected and power down time has been met.
- The SRS/Airbag system is equipped with a back-up source that powers the SRS/Airbag control unit for up to 3 minutes after disconnecting the 12 volt auxiliary battery.
- The seat side Airbags and the curtain shield side Airbags may deploy independently of each other.
- If the first stage is deployed in a dual stage frontal Airbag, the second stage may deploy itself due to heat within 3 minutes. Second stage does not re-inflate airbag at full strength.

