

Power Down Procedure #1

- ◉ **360 degree inspection**
 - From a safe distance
 - Check underneath vehicle
 - Immobilize and stabilize vehicle (chock wheels)
 - Silent running hazard
- ◉ **Observe dash for vehicle running status**
 - Ready light/illumination
- ◉ **Initial patient contact**
 - Use power options to maximize patient access (i.e. seats, windows, power locks)
- ◉ **Place vehicle in park, set parking brake**
- ◉ **Turn ignition off** (Power button or key)
 - Reach behind steering wheel (avoid Airbags)
 - Electronic smart key -Press power button once (multiple keys may be present)
- ▶ **Confirm ready light/dash illumination is off**
- ▶ **Turn off headlights** (HID ignition and shock hazard)
- ▶ **Turn on hazard lights** (indicates presence of 12V auxiliary battery power)
- ◉ **Locate and disconnect 12 volt auxiliary battery**
- ◉ **Confirm hazard lights are off**
 - Vehicle can not restart
 - SRS can not deploy
 - HID headlights can not operate
- ◉ **Continue with extrication procedures**

