

Component Locations: Bus

- Low voltage
 - Battery disconnect
- High Voltage
 - AC Traction Motor
 - Generator, three phase AC
 - Propulsion Control System (PCS)
 - Orange wires
 - NiMH Batteries

